

Configuration Manual KTC-IMC 3.4.0



1 Table of contents

- 1 Table of contents 2
- 2 Introduction 5
 - 2.1 Manual Conventions 5
 - 2.2 System overview 6
- 3 Getting started 7
 - 3.1 Installing the CMT Client 7
 - 3.2 Start IMC for the first time 7
 - 3.2.1 Alt 1 - By using DHCP (default on IMC network port 1) 8
 - 3.2.2 Alt 2 – By using static IP-address (default on IMC network port 2). 8
 - 3.3 Connect the CMT Client to IMC 9
 - 3.4 Access IMC through web interface 10
- 4 Connecting devices 11
 - 4.1 General information on topology 12
- 5 Handling ModBus devices 14
 - 5.1.1 Types of Modbus registers and their usage 14
 - 5.1.2 ModBus nodes 14
 - 5.1.3 Adding new Modbus devices to your topology tree: 15
 - 5.2 ModBus scan 25
 - 5.3 Recommended naming conventions 26
 - 5.4 Autocreate 29
 - 5.5 Auto create AV/DV object nodes 32
- 6 SRDLink 34
 - 6.1 To add a SRDLink device to your topology tree: 34
 - 6.2 Create SRDLink nodes via scan option 38
 - 6.3 Create SRDLink nodes via DAT file (Offline configuration) 40
 - 6.4 Create SRDLink nodes/Objects manually 41
 - 6.5 Activate Alarm Poll on SRDLink node 43
 - 6.6 Activate Serial Number Polling on SRDLink Node 44
 - 6.7 Connecting KTC device COM1025 using “SCADA-StatusClient” function with IMC 44
 - 6.8 Connecting KTC device using XMPP 47
 - 6.9 Communication Error 50
 - 6.9.1 Change Lockout Time and number of retries 50
 - 6.9.2 Gateway/Node Lockout Icon 51
 - 6.9.3 Manual override of lockout 51
 - 6.9.4 Communication Alarm 52
- 7 Custom View IMC 53
 - 7.1 Alarm view 54



- 7.2 SRDLink view..... 55
- 8 Mbus 57
 - 8.1 Add an Mbus device to your topology tree:..... 58
 - 8.2 Scan meters/devices..... 59
 - 8.3 Offline devices 61
- 9 Copy, backup and restore..... 62
- 10 Creating integrated functionality 63
 - 10.1 Generic info on creating calculation objects..... 63
 - 10.2 Generic info on object references..... 63
 - 10.3 AQ – Analog Calculation Object 64
 - 10.4 AT – Average Temperature Object..... 67
 - 10.5 AV - Analog Value Object 68
 - 10.6 DQ – Digital Expression Object..... 68
 - 10.7 DV - Digital Value Object 69
 - 10.8 HO - Holidays Object 69
 - 10.9 LR - Linear Regulator Object..... 69
 - 10.10 RW - ReadWrite Object 69
 - 10.10.1 Node Reference Input..... 69
 - 10.10.2 Node Reference Output..... 69
 - 10.11 ST State Object 70
 - 10.12 ST State Sequence Object..... 70
 - 10.13 SU - SunTimes Object 70
 - 10.14 TM - Thermostat Object 70
 - 10.15 TU - Timeschedule Object 70
- 11 Reading data from IMC..... 71
 - 11.1 OPC-UA..... 71
 - 11.2 Fast API..... 71
- 12 Creating IMC Alarms and Trend Data..... 72
 - 12.1 How to set up polled Alarm using AV/DV Objects 72
 - 12.2 How to set up polled Trend Data 73
 - 12.3 How to set up Alarms for SRDLink devices..... 74
 - 12.4 How to set up Trend Data for SRDLink devices 76
 - 12.4.1 Activate Trend Data collection via SRDLink View 76
 - 12.4.2 Activate Trend Data collection manually on every object 77
 - 12.4.3 Activate Trend Data collection on several objects at the same time 78
 - 12.4.4 General settings for the retrieval of historical values..... 79
- 13 Creating IMC Web GUI 81
 - 13.1 Creating a slide Show 81



| | | |
|--------|---|-----|
| 13.2 | Creating a menu | 85 |
| 13.3 | Creating a TrendView | 91 |
| 14 | Connecting to KTC Scada | 94 |
| 15 | Creating IMC dynamic flowchart/diagram | 95 |
| 15.1 | How to create a new diagram | 95 |
| 15.1.1 | The Diagrams tab | 95 |
| 15.1.2 | Start Diagram Designer | 96 |
| 15.1.3 | Adding a background image | 97 |
| 15.1.4 | Create a diagram link | 97 |
| 15.1.5 | Creating a value box | 99 |
| 15.1.6 | Creating a new dynamic symbol | 102 |
| 15.1.7 | Creating an editable value box | 107 |
| 15.1.8 | Create a description that is linked to the Diagram | 109 |
| 15.2 | How to save Objects to library | 110 |
| 15.3 | How to Copy/Paste and XML Export/Import of Custom Diagrams and Folders in the Diagrams/Library data sources..... | 113 |
| 15.3.1 | Copy/Paste objects in the Diagrams/Library data source from Server 1 to Server 2 | 113 |
| 15.3.2 | Export/Import objects in the Diagrams/Library data source from Server 1 to Server 2 | 114 |
| 16 | Using new Web Interface | 115 |
| 16.1 | Information Page..... | 115 |
| 16.2 | Navigation Menu | 116 |
| 16.3 | IP settings | 116 |
| 16.4 | License | 117 |
| 16.5 | Time Settings | 117 |
| 16.6 | Backup functions | 118 |
| 16.7 | Factory Reset..... | 119 |
| 16.8 | Restart IMC..... | 119 |
| 16.9 | Create Exports for Skanska Energy Box and Energy Portal | 120 |
| 16.9.1 | Erase Exports | 120 |
| 16.9.2 | Create new exports..... | 121 |



2 Introduction

IMC: The master control station for managed properties, places all energy devices and data on a common platform for management and monitoring.

Managed properties today consist largely of prefabricated systems with embedded control, monitoring, and communications capabilities. KTC IMC is a unique, powerful tool that gets property systems to work together, placing all managed systems on a single platform, making all their data easily accessible. This means that you can control devices/systems from a wide range of manufacturers rather than be restricted to any one brand.

KTC Integration Master IMC integrates all these systems to get them to cooperate and give you full control of the entire property. KTC integrates all devices and retrieves data from all technical systems on the property.

KTC IMC is scalable to any degree. It is typically installed in a cabinet in the central heating room of a large building with many apartments or offices to integrate the heating/cooling/ventilation systems in that building. It can also remotely control the systems in any number of other buildings from the same location.

Physically the IMC is a small embedded computer with network connections. All communications to programmer, user, PLC:s and other devices are via IP. The IMC doesn't include a screen so an external tablet, PC OS is needed for programmer and user.

2.1 Manual Conventions

The user manual is built more as a "how to" than as a reference. We go through the different steps in configuring and programming a plant using IMC. When there is user input required the dialog box and screen dumps is included, and a table describing the different fields and their meaning.

Since a lot of fields is generic, when possible there is a section in beginning of each chapter describing general info on the fields that is valid for all parts of the chapter.


There are a lot of fields that is rarely used so since this is not a reference manual they are sometimes excluded. The field description has a layout as below. The R column stands for "Required" and indicates that the field must always have data. The "Ex.data" column is only present in cases where the author finds it necessary to give some hint on good naming conventions, or reasonable values.

| Field | R | Description | Ex. Data |
|-------|---|-------------|----------|
| | | | |



2.2 System overview

The picture below describes how a system using IMC typically is built.



In Version 1.0 you can connect M-Bus, Modbus, SRDLink and XMPP devices over IP. More protocols are continuously added. The IMC creates functionality and control between different automation devices. As an extra it also creates a **one** GUI for the user so that he can control all different system for example from a tablet.

3 Getting started

To configure an IMC, you basically need to get it connected to a network, having the software tool “Clayster Management Client” CMT installed on your PC that is connected to the same network.

The end-user rarely needs the CMT, he will instead use the built-in webserver in IMC to access the system. This can be done from a pc, a tablet or a smartphone.

Much of the configuration that you do using the CMT can also be done directly in the web GUI, however not as efficient when doing larger amount of configuring.

Links to section contents:

- [Installing the CMT Client](#)
- [Start IMC for the first time](#)
- [Starting up and Connecting the IMC to the network](#)
- [Connect the CMT Client to IMC](#)

3.1 Installing the CMT Client

The CMT Client is the “configuring tool” for IMC and is included when an installer is educated on IMC System at KTC. The installer will receive the software at the education, or upgrades later from ktc.se

The setup file is named Clayster.Management.WPF.Setup.exe.

Run the setup file on the computer that will be used for configuring IMC. CMT Client is a windows tool and needs Windows operating system on a pc.

Follow the instructions given from setup program.



3.2 Start IMC for the first time

There are two ways to connect to an IMC for the first time. The following describes these two different ways.

3.2.1 Alt 1 - By using DHCP (default on IMC network port 1)


Connect the network cable to IMC IP port 1 to an existing network that has a DHCP-server. The IMC is default set to DHCP on IP port 1 and will be assigned an IP address.

If your network has a connection between DHCP-Server and DNS Server you will be able to reach the IMC by hostname. Hostname is default serial number i.e. S10Axxxx. You can find this serial number on the back side of the IMC.

Download the program "Angry IP Scanner". With help of this program you can do a search on all devices at your local IP range that respond to "ping" on port 50100 (default port for communication with IMC). For more information and downloads of Angry IP Scanner see <http://angryip.org>

By comparing the result of a "scan" before and after IMC connected to the network, you can find your IMC. Normally only IMC will responds on port 50100, and then only the IMC's connected to the network.

Tip: Enable MAC Address in Angry IP. Then you will also see the MAC address of the devices that responds on port 50100. Compare the MAC address in the list with the one on the sticker on the IMC.



3.2.2 Alt 2 - By using static IP-address (default on IMC network port 2).


Connect the network cable to IMC IP port 2. This network card is default set to static IP address 192.168.0.5.

By configuring the network card on your PC to be in the same range (e.g. 192.168.0.10), you can connect directly to your IMC.




3.3 Connect the CMT Client to IMC

When starting the CMT Client the dialog below will be displayed. It allows you to connect to the IMC and start configuration. Once you have connected it will be easier to reconnect since the connections are saved under "recent connections"




| Field | R | Description | Default on IMC |
|------------------|---|---|----------------|
| Connection Name | R | Simpler name than IP to remember | |
| User | R | User name | Admin |
| Password | R | Password | Admin |
| Host | R | Hostname or IP-Address of IMC. | |
| Port | R | Port number to communicate on | 50100 |
| Direct to Server | R | Always use this for IMC | |
| Work Area | | If you have saved a file with configuration of your workspace you can load this here. | |

Once connected the screen will look as below. Then everything is ready to start configure....




3.4 Access IMC through web interface.

Connect by opening a browser and enter the IP address or the name of your IMC followed by the port number: 8080. Fill in the username and password and click "OK".




IMC is loading...



4 Connecting devices

This section for the installation engineer and describes how to configure and connect to different devices using different protocols.

All device configurations are done in the **topology**. The topology is the network of devices that IMC controls. To access the topology, select datasource – metering – topology as shown in picture below.



Once topology is opened it will get a tab and you access it by clicking on that tab.

This chapter is divided into some general information and then one section for each protocol available at writing time. The number of protocols is continually extended, and will be described in future versions of this manual.


Link to sections on how to configure the topology

- [General information on topology](#)
- [ModBus](#)
- [SRDLink](#)
- [Mbus](#)



4.1 General information on topology

On an IMC the standard topology has the following “top” nodes.



Alarminfo - Special node that provides functionality for Sum alarms for all other nodes.


Mbus - All Mbus devices connected to the system will be added to this node

Modbus - ModBus devices

SRDLink – KTC SRDLink Devices.

Object – Integration function and calculations

When adding new nodes just select the node that you want to add a device or node under, right click and select “add”. Depending on where and what you want to add a dialog box will appear. However many of the fields is similar between different objects that you add. A Dialog box similar to the one below will appear.





Some fields and tabs in the dialog box are unique to the type of object you want to add, but many fields are identical. This manual will describe the generic fields valid for all objects. More specific fields for a specific type of object are described in the part of the manual that describes these objects.

| Tab | Field | R | Description | Ex. Data |
|-------------------------|-------|----|--|-------------------------------|
| Id | Id | R | Unique id for the node. In many cases the system will suggest an id based on the parents id. It is important to have some kind of system for naming nodes/devices. | B01.TA01.AI01 B01.FF01.A60 |
| Required User Privilege | .. | .. | .. | .. |

5 Handling ModBus devices

Modbus is a standard serial communications/ control protocol for use with programmable logic controllers (PLCs). It provides communication between devices connected on buses or networks. Modbus allows for communication between many networked devices. An example is a system that measures temperature and humidity and communicates the results to a computer. Modbus is often used to connect a supervisory computer with a remote terminal unit (RTU) in supervisory control and data acquisition (SCADA) systems.

The protocol defines function codes and the encoding scheme for transferring data as either single points (1-bit, coils) or as 16-bit data registers. This basic data packet is then encapsulated according to the protocol specifications for Modbus ASCII, RTU, or TCP.

Modbus protocol is defined as a master/slave protocol. That means a device operating as a master will poll devices operating as slaves. The master will write and read data from slave devices.

5.1.1 Types of Modbus registers and their usage

- **Coils** are 1-bit registers, are used to control discrete outputs, and may be read or written.
- **Discrete Inputs** are 1-bit registers used as inputs, and may only be read.
- **Input registers** are 16-bit registers used for input, and may only be read.
- **Holding registers** are the most universal 16-bit register, may be read or written, and may be used for a variety of things including inputs, outputs, configuration data, or any requirement for "holding" data.

5.1.2 ModBus nodes

The below is a typical structure for ModBus Nodes

Modbus Root node


- ModbusGateway
- ModbusNode
 - Coil Register
 - DiscreteInput Register
 - Modbus Group
 - Modbus group
 - Register group
 - Holding Register
 - Input Register
 - Modbus Register Group
 - Coil Register (a digital **read/write** object): Compares read/write with relay.
 - DiscreteInput Register (a digital **read** object): Digital input
 - Holding Register (an analog **read/write** object): To persist whatever is written.
 - Input Register (**read** object): Reads analogue values.



5.1.3 Adding new Modbus devices to your topology tree:

Begin with a ModBus gateway.

Right-click the Modbus root node, and select the "Add/Modbus Gateway" option:





On the ID tab:

Id required

A unique Id for the system to use for this node. Can be autocreated via the [Autocreate](#) function.

Description optional

A freely chosen description of the node. It will appear in the tree.

Required User Privilege optional

If empty, all can view this node. If not empty, this node (and all its children) can only be viewed by users having this Privilege ID.

Name required

A secondary name (string) for the node. It appears in the tree. Is used in the [Autocreate](#) ID function.

Class required

Select the type of device. Possible values are: ColdWater, Gas, Electric, Concentrator, , etc.

Phase required

- Test: cannot erase nodes.
- Production: cannot erase nodes or edit some com parameters.
- Install: all new nodes default)

Enabled optional

Enables function. Default= true

MeterLocationId optional

ID of the meter location. Is often used in meter data application to assign values. It is recommended to assign a meterLocationId. It is used by engineers to locate meters/sensors upon customer request.

MeterNumber optional

Often used in metering apps to assign values.

Suggested naming conventions:

- In general, try to create groups that match the functions in a Modbus unit, typically one group for each sensor, or for each control function.
- If the unit is to be connected to KTC Scada, try to match SRDLink objects to avoid creating new interfaces at the top level.
- If IMC is serving only one building, use the name of the unit connected:
Example: a single building Alarm setting could be named **LS01**
- If serving several buildings, add some information to identify the building connected.

Example: If there is a gateway for each building, it could be named **ModbusGW-Bldg 6**.




Naming convention for IDs:

It is suggested to use **AAxx** where AA is the recommended abbreviation and **xx** is the ModBus address. There might be (for example): a Modbus gateway with an IP-address, and a main module with a ModBus address, and a number of submodules. This naming convention makes it easy to organise them. See chapter 5.3 below.

Note: The ID can be auto-created as a concatenation of node names in the path to the final object. Take this into consideration when assigning Modbus Names. See Autocreate below.

On the Communications tab:



ThreadGroup *optional*

Thread Groups can help performance. Nodes of the same thread group are read using the same thread. If not specified, the node automatically assigns a thread group with the same name as the node ID.

Host *required*

Host Name or IP Address of the machine or device.

Port *required*


Port Number to use when connecting to the machine or device. standard for ModBus is 502.

Then add a ModBus Node to the gateway


Note that you can add a ModBus node manually as follows or via the scan function (see ModBus scan).

Often only one on a Gateway, but can be several.

Right-click the Modbus gateway selecting the Add/Modbus Node option:



On the ID tab:



Node Type:
Modbus Node

Parameter Templates

ID Modbus Scan result Geography Colors

ID:
LA01.A60

Description:
A60

Required User Privilege:

Name:
A60

Class:
Other

Lifecycle Phase:
Installation

Enabled

Meter Location ID:

Meter Number:

Revert

Id *required*

A unique Id for the system to use for this node. Can be autocreated via the [Autocreate](#) function.

Description *optional*

A freely chosen description of the node. It will appear in the tree

Required User Privilege *optional*

If empty, all can view this node. If not empty, this node (and all its children) can only be viewed by users having this Privilege ID.

Name *optional*

A secondary name (string) for the node. It appears in the tree. Is used in the [Autocreate](#) ID function.

Class *required*

Select the type of device. Possible values are: ColdWater, Gas, Electric, Concentrator, etc.

Phase *required*

- Test: cannot erase nodes.
- Production: cannot erase nodes or edit some com parameters.
- Install: all new nodes default)

Enabled *optional*

Enables function. Default= true

MeterLocationId *optional*


ID of the meter location. Is often used in meter data application to assign values. It is recommended to assign a meterLocationId. It is used by engineers to locate meters/sensors upon customer request.

MeterNumber *optional*

Often used in meter data application to assign values.



On the Modbus tab:



Modbus address *required*

Enter the Modbus address from the project documentation.

Singlewrite functionCode *required*

Function code to use when writing to a single holding register.

Options are:

- Single
- Multiple


Register Word order *required*

Register word order to use when registering 32 bit values.

Options are:

- LSW-MSW
- MSW-LSW

On the Scan Result tab:



Scan Result Shows the results of the last scan.

Scan is done by right-clicking on that Modbus node you want to search and select " scan detailed".

Set " Register type ", "Starting address", "Ending Address" and "Maximum quantity per message".

Click "OK" to execute.

On the Geography tab: Not necessary

On the Colors tab: Not necessary




Then add a Modbus Register:

You can add a register group to create a group that connects variables in Modbus related to a specific object.

In this example, add a single Register.

Right-click the **Modbus node**, selecting the **Add** option and then the register of choice, in this case, a **Modbus Holding Register**:





On the Id tab:

Note: At this level of the tree, different nodes can have different functions. The tabs presented in this section of the manual show all possibilities. Therefore, some of the following attributes/tabs might NOT be available to you, depending on the node type you are adding:

Id *required*

A unique Id for the system to use for this node. Can be autocreated via the [Autocreate](#) function.

Description *optional*

A freely chosen description of the node. It appears in the tree.

Required User Privilege *optional*

If empty, all can view this node. If not empty, this node (and all its children) can only be viewed by users having this Privilege ID.

Name *optional*

A secondary name (string) for the node. It appears in the tree. Is used in the [Autocreate](#) ID function.

Class *required*

Select the type of device. Possible values are: ColdWater, Gas, Electric, Concentrator, etc.

Phase *required*

- Test: cannot erase nodes.
- Production: cannot erase nodes or edit some com parameters.
- Install: all new nodes (default).

Enabled *optional*

Enables function. Default= true

MeterLocationId *optional*

ID of the meter location. Often used in meter apps to assign values. Recommended to assign it. Used to locate meters/sensors upon customer request to helpdesk


MeterNumber *optional*

Often used in meter data application to assign values.



On the Register tab:

Note: At this level of the tree, different nodes can have different attributes. The tabs presented in this section show all possibilities. Some of the following attributes/tabs might NOT be available to you, depending on the node type you are adding:





- Register:** *required*
Enter register address. Default addresses are usually specified in unit documentation.
 - Size:** *required*
Select value size, 16 or 32 bit
 - Datatype:** *required*
Select register datatype (signed, unsigned or float)
 - Unit:** *required*
Select units (°C, kWh, sec, etc)
 - Offset:** *optional*
Enter offset that will be added/subtracted from collected value. Typically for calibration, normally not used.
 - Multiplier:** *optional*
Example: If a value is expressed in 0.1 degrees, enter a multiplier to process it to a more useable number.
 - Start bit range:** *optional*
Select bit range start (1-32) 0=disable (reads entire reg)
 - End bit range:** *optional*
Select bit range end (1-32)
0=disable (reads entire reg)
 - Enumeration list:** *optional*
Add string in format (Index=String) to create an Enumeration list.
- Note** the icon that exports this to the editor if you prefer to work there.




5.2 ModBus scan

You can use the built-in scan function to read the Modbus registers in the Modbus device. Right-click the Modbus Node, selecting the **Scan detailed** option:



- Register type:**
Select the type of register to search for.
- Starting address:**
Starting address for individual address search range.
- Ending address:**
Ending address for individual address search range.
- Max quantity per message:**
The maximum number of Registers to include per message.





5.3 Recommended naming conventions

The format for naming is **NodeName.NodeName.RegisterName**. It is further recommended to use the same object names as in SRDLink objects. This avoids creating new top level groups and improves performance, particularly if used in connection to KTC-SCADA. The following image shows the names typically used. Consult the KTC-modules guide for the latest updates.


NodeName.NodeName.RegName

DUC (SRD Link 2)

- 1 - SRD5000 (SRD5301-1301)
 - AI - Analog in
 - AQ - Calculated value
 - AU - Analog out
 - AV - Analog value
 - AZ - 3 point out
 - AZ01 -
 - AZ02 -
 - CS - Communications
 - DI - Digital in
 - DQ - Set points
 - DU - Digital out
 - DV - Digital value
 - FV - Frost guard
 - HR - Event counter
 - KL - Yearly calendar
 - KV - Curves
 - LR - Linear calculations
 - LS - Alarm setting
 - LS - Alarm setting
 - MB - Meters
 - MM - MM
 - MT - Exercise
 - PU - Pump control
 - RC - Controls
 - RL - RL
 - RT - Real time clock
 - SK - Step controller
 - TB - Trend buffer
 - TM - Thermostats
 - TO - Timer object
 - TR - Time relays
 - TU - Timers
 - UI - Universal in
 - VK - VK
 - VX - Change
 - XE - XE

The following image shows how the various identification components are displayed in the tree, and a logical approach to configuring these entries.

Note: the [Autocreate](#) option for auto-generating the IDs to be used in the system:




Summary of recommended naming tips:


- Use the same abbreviations used in the SRDLink module when naming nodes. SRDLink is the software protocol for KTC-specific products. Performance is thus improved, particularly when connecting to other KTC modules such as KTC SCADA.
- If you have variables that don't easily convert to the SRDLink model, you can add each to a random group with any name that makes sense to you.
- Note that the **Description** fields for each node, add visible information to the tree that makes it easy to locate an object for management/trouble-shooting etc. Examples:
 - Include Register addresses in the descriptions of folders that organise ModBus registers. **A60** might indicate a folder of airhandling variables at address 60 behind the Modbus gateway.
 - In addition to SRDLink abbreviations, text that indicates usage such as building/apartment numbers, or titles such as Settings, Airhandler etc. are useful in descriptions.



- To translate a Boolean/int variable to text, use the **Enumeration** list function.



The value will be shown as text described in the **Enumerationlist**:





5.4 Autocreate

For Modbus objects, you can use Autogenerate to create the final **ID** of the object that is used by the system. This function automatically concatenates the contents of the **Name** fields for all nodes in the path to the final object. The following section demonstrates this.


When configuring the Modbus ID tabs (for gateways or sub-nodes), you must enter something in the **ID** field in order to make the **OK** button available. If you plan to use Autogenerate, you can enter anything you want because it will be replaced when the final ID is calculated. In this example, the gateway ID is anything, the **name** is **LA01** (the SRDLink abbreviation for an air handling unit with the gateway contained). The description is **Bldg1-Airhandling**. It will appear in the tree to inform the user of the unit's purpose. The address of the unit will also appear in the tree from what you enter on the **Communication** tab:

The screenshot shows a configuration window for a 'Modbus Gateway'. At the top, 'Node Type:' is set to 'Modbus Gateway'. Below this are four tabs: 'ID', 'Communication', 'Geography', and 'Colors'. The 'ID' tab is active and contains the following fields:


- ID:** Text box containing 'anything'.
- Rename descendants**
- Description:** Text box containing 'Bldg1-Airhandling'.
- Required User Privilege:** A dropdown menu that is currently empty.
- Name:** Text box containing 'LA01'.



Adding a subnode, you can again enter anything in the ID field and then enter a name in the Name field. This example adds a node named **A60**. The description is also **A60**. This will appear in the tree as A60 (A60) with the description first and name in parenthesis. In this case, A60 is used to inform the user of the unit address behind the integrated gateway (default addresses are usually specified in unit documentation):




Configure as many levels of sub-nodes as you wish. When you are finished, right-click the Modbus GW or Modbus Node you have added them to, selecting the **Set standard ID** option:



Now looking at the Properties tab of a final object (below, it's **Ai (Value)**): you can see that:

- The node **Names** are unchanged in the tree
- The **Ids** have now been replaced with the concatenation of node names in the path leading to the final object: In this example, it is **LA01.A60.Ai01.Value** identifies the holding register that contains the Ai value.



5.5 Auto create AV/DV object nodes


Modbus Input Register, Modbus holding register, Modbus Coil Register and Modbus DiscreteInput Register can auto create an object node with a reference to the Modbus node itself.

Modbus Input Register and Modbus holding register will generate AV objects and Modbus Coil Register and Modbus DiscreteInput Register will generate DV objects.

The new node(s) will be created under systems Object folder with the same name as the Modbus node that contains the selected node and with dash Modbus after the name, e.g.
MyModbusNodeName - Modbus


The object node name will have the same name as the Modbus node name. The object id will have the format: *Object.DV.ModbusRegisterId.Modbus*, where ModbusRegisterId is the same Id as the origin Modbus register node.

To create a new object node, right click on the Modbus register node and select “Create AV node” or “Create DV node” depending on what type of Modbus node you have selected (Input/Holding or Discrete/Coil).






To create object nodes for all Modbus register items under a Modbus node, select “Create object nodes...” by right clicking on the Modbus node. And click “Yes” on the popup window.



The new object nodes with references under Object -> New folder (in this example DUC – Modbus):






6 SRDLink

SRDLink is the software protocol for KTC-specific products. KTC products also supports other protocols but the native protocol is SRDLink.

- SrdLinkGateway
 - o SrdLinkNode
 - SrdLinkObject
 - SrdLinkObjectGroup
 - SrdLinkObject
 -

6.1 To add a SRDLink device to your topology tree:

Begin by adding a **SRDLink gateway** node:





The ID tab: Enter the ID and Name (often the same).


The screenshot shows a software dialog box titled "New child to Site #1". At the top, there is a "New Node Type:" dropdown menu set to "SRD Link Gateway". Below this is a "Parameter Templates" section with a dropdown arrow. The main area is divided into tabs: "ID", "Communication", "DAT Files", "Backup", "Geography", and "Colors". The "ID" tab is active and contains the following fields:

- ID:** A text input field containing "NET001".
- Required User Privilege:** A dropdown menu.
- Name:** A text input field containing "NET001".
- Owner:** An empty text input field.
- Class:** A dropdown menu set to "Other".
- Lifecycle Phase:** A dropdown menu set to "Installation".
- Enabled:** A checked checkbox.
- Meter Location ID:** An empty text input field.
- Meter Number:** An empty text input field.

 At the bottom of the dialog are three buttons: "Revert", "OK", and "Cancel".

- Id** *required*
A unique Id for the system to use for this node.
- Required User Privilege** *optional*
If empty, all can view this node. If not empty, this node and children can only be viewed by users with this Privilege ID.
- Name** *optional*
A secondary name (string) for the node. It appears in the tree. Is used to inform about usage of the objects.
- Class** *required*
Select the type of device. Possible values are: ColdWater, Gas, Electric, Concentrator, , etc.
- Phase** *required*
-Test: cannot erase nodes.
- Production: cannot erase nodes or edit some com parameters.
- Install: all new nodes default)
- Enabled** *optional*
Enables function. Default= true
- MeterLocationId** *optional*
ID of the meter location. Often used in meter apps to assign values. It is recommended to be used by engineers to locate meters/sensors.
- MeterNumber** *optional*
Meter apps can use to assign values.

On the Communication tab: Enter the IP-address and port number to reach the unit, standard port for SRD Link is 10001.



Properties

Node Type:
SRD Link Gateway

Parameter Templates

ID Communication DAT Files Backup Geography Colors

Thread Group:
[Empty]

Host:
192.168.100.139

Port Number:
10001

Line Listener subfolder:
[Empty]

Verbose Line Listener

Scan alarms

Synchronize time

Revert OK Cancel Apply

ThreadGroup *optional*

Thread Groups can help performance. Nodes of the same thread group are read using the same thread. If not specified, the node automatically assigns a thread group with the same name as the node ID.

Host *required*

Host Name or IP Address of the device.

Port *required*

Port Number to use when connecting to the device. Standard for SRDLink is 10001.

Line listener subfolder *optional*

Enter the name of a line listener subfolder. Leave empty if no line listener is desired.

Verbose line listener *optional*

If checked, additional info is provided in the line listener.

Scan alarms *optional*

Scans the alarm queue.

See chapter 7.1 and 7.3 for further information regarding alarm setup.

Synchronize time *optional*

Synchronize times.

DAT Files tab: This is an alternative for adding SRDLink nodes. See: [Create SRDLink nodes via DAT file \(Offline configuration\)](#)

Backup: Here we can see when the last backup of the PLC is made.

To make a PLC backup, right click on the SRD-Link Gateway and select "Read DAT file". The files will by default be stored under: C:\ProgramData\IMC\DATFiles

Geography tab: unnecessary.

Colors tab: unnecessary.


There are three ways to add SRD-Link devices.


1. Scan: automatic scanning of devices. This is the easiest way and requires a minimum of time. This method requires that devices are accessible from the IMC server.
2. Import DAT-files: We use this method when we want to prepare the OPC server and not yet have communication to the devices.
3. Manually build the SRD-Link topology: This method is the most time consuming and is primarily used to add single objects in a device.



6.2 Create SRDLink nodes via scan option

Right click on the SRD-Link Gateway and select “scan detailed”.





Use VER Default method. Fastest scan but can be unreliable with many devices connected to the bus.

Individual search More time consuming but more reliable with a large number of devices connected.


Starting address Beginning address for the individual address scan range.

End address End address for individual address scan range.

Timeout Timeout in ms for address queries.

Tries Number of tries before returning a failure.

Every existing device and object connected to the SRD-Link Gateway will automatically be placed in your topology tree.






6.3 Create SRDLink nodes via DAT file (Offline configuration)


For convenient logistics, you can pre-program a building with an offline configuration. This method allows you to create a SRDLink gateway node with SRDLink devices and objects by importing a DAT file at the gateway level.

DAT Files are created by using the KTC Tool Automate, for more details read the manual for Automate.

Start by uploading your already configured DAT files to the "SRD Link Gateway".




Right click on the "SRD Link Gateway" and choose "Import DAT".



6.4 Create SRDLink nodes/Objects manually

Add a SRD-Link device node to the gateway by right-clicking the SRD Gateway and selecting the **Add/DUC** option:



Id *required*

A unique Id for the system to use for this node.

Required User Privilege *optional*

If empty, all can view this node. If not empty, this node (and all its children) can only be viewed by users having this Privilege ID.

Name *optional*

A secondary name(string) for the node. It appears in the tree. Is used to inform about usage of the objects.

Class *required*

Select the type of device. Possible values are: ColdWater, Gas, Electric, Concentrator, , etc.

Phase *required*

- Test: cannot erase nodes.
- Production: cannot erase nodes or edit some com parameters.
- Install: all new nodes default)

Enabled *optional*

Enables function. Default= true

MeterLocationId *optional*

ID of the meter location. Is often used in meter data application to assign values. It is recommended to assign a meterLocationId. It is used by engineers to locate meters/sensors upon customer request.

MeterNumber *optional*


Often used in meter data application to assign values.

On the Communication tab: Enter the SRD-address and model type of the unit.



After this you can add a **SRD-Link Object/ SRD-Link Object Group**(used to organize the objects)
Just right click and chose the type of object you want to add.


On the Communication tab you have to fill in the Object Name and number.





6.5 Activate Alarm Poll on SRDLink node

With this optional parameter it is possible to activate alarm poll. No value or 0 will disable the function. Put a number for the interval in minutes that this SRDLink Node (DUC) will be polled. If no alarms are detected, a short alarm scan will be done, looking for sum-alarm of the node. If any alarm is active, a full alarm scan will be done each time in order to detect eventual change of status in the alarm(s). Alarm polling will consume more data which should be considered if using serial communications.






6.6 Activate Serial Number Polling on SRDLink Node

This setting automatically updates the serial number on the DUC Node.

Serial Number Polling can be set on SRDLinkNode (DUC) or in Settings. Value is set in hours. 0 or no value is disabled function.

Note: This setting affects all SRDLink Nodes regardless where it is set.




6.7 Connecting KTC device COM1025 using "SCADA-StatusClient" function with IMC.


In the communication product KTC COM1025 there is a function called "SCADA Client Status". This feature enabled communication between COM1025 and former Adepto OPC server without the use of fixed IP addresses. At IMC, we have implemented functionality to be able to support KTC COM1025 fully in the IMC.

The first thing we must do is to add a SRDLink server. This is to allow communication between COM1025 and the IMC server.

Open **Data source/IMC/SRDLinkServer**.


Add SRDLink Server






- Name:** Enter a name for the node
- Protocol:** TCP/UDP (in this case we use TCP)
- Port Number:** Enter a valid port number for the connection to the host machine. Default for this application is 10001.

Those COM1025 devices configured to talk to your IMC server will now appear in the tab **Data source / IMC / Status Client (COM1025)**.



What remains now is to create a reference to Topology tree. We do this by adding a **SRDLink Gateway reference**.




Note: This reference replaces any communication settings previously made in Topology / SRDLink Gateway with new ones from the Status client.




6.8 Connecting KTC device using XMPP

In IMC, you also have the ability to connect your devices through XMPP. Connection via XMPP does not require fixed IP addresses and only port for outgoing traffic must be opened (default XMPP port 5222). An XMPP server must be available for this type of communications solution.

Add a new XMPP Server:



Fill in settings for communication with the XMPP server you are connecting to in the Communications tab:



The screenshot shows the 'Properties' dialog box for an XMPP Server. The 'Node Type' is 'XMPP Server'. The 'Communication' tab is selected, showing the following fields and options:

- Thread Group:** (empty text field)
- Host:** xmpp.utv.ktc.se
- Port Number:** 5222
- XMPP Domain:** xmpp.utv.ktc.se
- XMPP Address (JID):** pan01@xmpp.utv.ktc.se
- Password:** (masked with dots)
- Trust invalid server certificates.
- Auto-create account if not available.
- Display Heart beats in line listener.
- Seconds between reconnection attempts:** 60

Buttons at the bottom: Revert, OK, Cancel, Apply.

Thread Group *optional*

All nodes belonging to the same thread group, will be read using the same thread.

Host *required*

Enter an IP address or DNS name for the host machine

Port Number *required*

Enter a valid port number for the connection to the host machine.

XMPP Domain *required*

Name of the domain hosted by the XMPP server.

XMPP Address (JID) *required*

XMPP address of the client that will perform communication with XMPP devices.

Password *required*

Password corresponding to the XMPP address.

Trust invalid server certificates *optional*

If checked, invalid server certificates will be accepted during connection.

Auto-create account if not available *optional*

If checked, a new account will be created on the XMPP server. After created, the flag will be cleared.

Display Heart beats in line listener *optional*


If checked, the line listener will display when heart beat messages is sent to the XMPP server.

Seconds between reconnection attempts

If connection to XMPP server is missing, reconnection attempts will be performed with this interval.



Any valid connections will show up in the XMPP topology:



6.9 Communication Error

If there is a problem with the communication to an SRD-gateway or an SRD-node (DUC), the unit will be temporary disabled to avoid unnecessary load on the system and communication. After a specified time, the IMC will automatically retry to establish connection with the disabled node. If a gateway is disabled, all SRD-nodes (DUCs) that belongs to the gateway will also be disabled.

6.9.1 Change Lockout Time and number of retries

To change the default time, which is set to 10 minutes for both gateway and node, the file "KTC.Common.Settings.xml" can be edited.

In the "C:\ProgramData \IMC\KTC.Common.Settings.xml" file, there are four xml elements to manually adjust times and try for gateway and nodes. If these rows are omitted in the config file, the default times will be used (10 minutes and 4 retries).

- gatewayCommunicationLockoutTime (in minutes) - How long a gateway will be disabled, default 10 minutes unless specified.
- gatewayCommunicationMaxErrorTries (number of attempts) - Number of attempts that are made before a gateway is disabled, default 4 try if not specified.
- nodeCommunicationLockoutTime (in minutes) how long a SrdNode (DUC) will be disabled, default 10 minutes unless specified.
- nodeCommunicationMaxErrorTries (number of attempts) - - Number of attempts that are made before a srdNode (DUC) is disabled, default 4 try if no specified.

Caution! If the XML file is incorrect (spelling error etc.) while loading, topology will be removed at startup!!!

Example:

```

<?xml version="1.0" encoding="utf-8"?>
<Settings xmlns="http://ktc.com/schema/Settings/v1.xsd">
  <authenticateClients>true</authenticateClients>
  <ccsServer>true</ccsServer>
  <productName>CCS</productName>
  <alarmScanIntervalMinutes>5</alarmScanIntervalMinutes>
  <OpcServerSettings readInterval="10000" samplingInterval="2000">
    </OpcServerSettings>

  <gatewayCommunicationLockoutTime>5</gatewayCommunicationLockoutTime>
  <gatewayCommunicationMaxErrorTries>1</gatewayCommunicationMaxErrorTries>
  <nodeCommunicationLockoutTime>3</nodeCommunicationLockoutTime>
  <nodeCommunicationMaxErrorTries>2</nodeCommunicationMaxErrorTries>

  <fieldSinkId>
  </fieldSinkId>
</Settings>

```


6.9.2 Gateway/Node Lockout Icon

If an SRD-gateway or an SRD-Node is disabled by the system, it will have an overlay icon. The picture below shows an example how the icon looks like, a warning triangle.



6.9.3 Manual override of lockout

To manually override the disabled node and try to establish connection before the timeout, right click on the disabled node -> Click 'Cancel lockout'. If there is still a communication problem, the node will automatically be disabled again after the retries.






6.9.4 Communication Alarm

Communication Alarm is an alarm activated when an SrdLink Node has communication problems.

| Id | Status | Ack. | Time | | |
|-------------------|--------------|-------|---------------------|-------------------------------------|--|
| RCU10.DUC010.RCU1 | Sensor error | Ackn. | 2021-03-17 13:16:46 | <input checked="" type="checkbox"/> | |

To activate Communication Alarm for an SRDLink node, use settings and click “Activate SrdNode Communication Alarm”. After this setting has been activated, restart IMC.






7 Custom View IMC


The IMC includes two different custom views. These two are the **Alarm view** and **SRDLink view**. The **Alarm view** is used to monitor and acknowledge alarms. **SRDLink view** can be used to monitor real-time values of Object, see when the last backup was taken and activate trend collection on Objects and more.

Both are closely linked to the Topology tree and displays information depending on which node in the tree you have selected.

Custom views are accessed via the **View / Alarms view alt. SRDLink view**. A prerequisite for being able to open custom views is that **Topology** is already selected.




Alternatively, custom views can be opened via the **Topology tree / Open View**.





7.1 Alarm view

Alarm view is a list with the possibility to Filter, acknowledge and delete alarms. Alarms are displayed related to the selected node in the topology tree. It means that you will see all alarms in the IMC if you select the top node.




Acknowledging alarms is done by clicking:

Permanently remove an alarm is done by clicking:

Refresh the Alarm view by clicking:


By clicking on an alarm, you will get more information about the specific alarm.






7.2 SRDLink view

At the gateway level, it provides information about Backups, current alarm settings in the PLC (click on the PLC name) as well as connection info.



At the PLC level, you can see when the last backup was taken. You are also able to activate historical collection of objects (see [Chapter 11.4.1 for more information](#)).





On the object level, you will find real-time data for the selected object.

The screenshot shows the SrdLink View interface. On the left is a 'Topology' tree with the following structure:

- Root
 - AlarmInfo
 - SRD-Link-Gateway-1 (192.168.100.207)
 - 1 - DUC001 (SRD5301-1301)
 - Analogt
 - AQ - Beräkn. värden
 - AV - AV
 - AV01 - RT-UTE**
 - AV02 - IV-RT451
 - AV03 - IV-RT551
 - AV04 - IV-RT502
 - AV05 - VV-RT451
 - AV06 - VV-RT511
 - AV07 - VV-RT551
 - AV08 - FV-RP401
 - AV09 - FV-RP402
 - AV10 - FV-RP501
 - AV11 - IV-SB401
 - AV12 - IV-SB402
 - AV13 - VV-SB411
 - AV14 - DP-FILTER
 - AV15 - DP-PRIMÄR
 - AV16 - DP-CENTRAL
 - AV17 - MomentanFörbr
 - AV18 - Begränsningsnivå
 - AV19 -
 - AV20 -
 - AV21 - IV-RT451(Framl.) LAI
 - AV22 - VV-RT451(Framl.) LA
 - AV23 -
 - AV24 -
 - AV25 -
 - AV26 -
 - AV27 -

On the right, the 'SrdLink View' panel displays the following real-time data for the selected object:

| Property | Value |
|-------------------------|------------|
| Text | RT-UTE |
| Tag | |
| Kategori | 0 |
| CategoryText | --- |
| Signalval | A101va |
| Värde | 24,08 °C |
| Utgångsstatus | 24,08 |
| Enhet | 1 |
| UnitText | °C |
| Minbegränsning | |
| Maxbegränsning | |
| Villkor min | 0,00 |
| Villkor max | 0,00 |
| Max | 24,10 °C |
| Min | 24,05 °C |
| MinMax reset interval | 2 |
| MinMaxResetIntervalText | Dag |
| Manöverläge | 0 |
| ModeText | Auto |
| Handställt värde | 1,00 °C |
| Givarfelstatus | 0 |
| AlarmSensorStatusText | Ej Larm |
| Larmstatus | 0 |
| AlarmStatusText | Ej Larm |
| Fördröjning | 0 sek |
| Larmprioritet | 3 |
| AlarmPriorityText | A-larm |
| Höglarmgräns | 60,00 °C |
| Låglarmgräns | 0,00 °C |
| Larmförregling | |
| Larmtid | 6.06:00:00 |
| Larmdatum | 0001-01-01 |
| Tid kvittering | 6.06:00:00 |
| Datum kvittering | 0001-01-01 |

8 Mbus

M-Bus (Meter-Bus) is a European communications standard for the remote reading of gas or electricity meters. M-Bus is also usable for other types of consumption meters. The M-Bus interface is made for communication on two wires, making it very cost effective.

M-Bus was developed, for example, to measure the consumption of gas or water in the home. This bus fulfils the special requirements of remotely powered or battery-driven systems, including consumer utility meters. When queried, the meters deliver the data they have collected to a common master, such as a computer, connected at periodic intervals to read all utility meters of a building.

Other applications for M-Bus are alarm systems, flexible illumination installations, heating control, various sensors etc.

Note that M-Bus provides functions for scanning the network, automatically registering discovered nodes that are connected to the system.


Examples of Mbus devices:

- MBusIPGateway
 - MbusNode
 - SVM TBox Mbus Temperature Sensor
 - Westermo AD01
 - Mbus Adapter
 - MBussMaster
 - R232 Master
 - Sharky 773
 - Sharky 775
 - Enermet11EVLMBus
 - PiiGAB900
 - MBusInterface



8.1 Add an Mbus device to your topology tree:

- Right-click in the topology tree where you want to add the new node (here, it is the Root node).
- Select the **Add** option for the correct node-type. In this case, add an **Mbus gateway** to accept the specific Mbus devices you want to connect:



On the ID tab:

Id *required*

A unique Id for the system to use for this node.

Required User Privilege *optional*

If empty, all can view this node. If not empty, this node (and all its children) can only be viewed by users having this Privilege ID.

Name *optional*

A secondary name (string) for the node. Gives info to users about the node, instead of the id attribute.

Class *required*

Select the type of device. Possible values: ColdWater, Gas, Electric, etc

Phase *required*

-Test: cannot erase nodes.

- Production: cannot erase nodes or edit some com parameters.

- Install: all new nodes default)

Enabled *optional*

Enables function. Default= true

MeterLocationId *optional*


ID of the meter location. Is often used in meter data application to assign values. It is recommended to assign a meterLocationId. It is used by engineers to locate meters/sensors upon customer request.

MeterNumber *optional*

Often used in meter data application to assign values.



On the Communication tab



Thread Group *optional*

Thread Groups can help performance. Nodes of the same thread group are read using the same thread. If not specified, the node automatically assigns a thread group with the same name as the node ID.

Host *required*

Host Name (string) or IP Address of the machine or device.

Port Number *required*

Port Number to use when connecting to the machine or device. KTC Devices normally connects on port 10003, UDP

IP protocol *optional*

Specifies the IP protocol to use. Possible values are: TCP (Default), UDP


Verbose Line Listener *optional*


If true, interpretation information will be made available in the line listener. Default is false.

8.2 Scan meters/devices.

You can scan for either primary or secondary address. Recommended is secondary.

When you have established an M-Bus gateway, you can use the scan function to discover all devices connected on the bus. Right-click the gateway, selecting one of the Scan options.






Timeout *optional*
 Value in milliseconds. Default is 0

Tries *optional*
 Max inclusive value is 100. Default is 3.

Any nodes discovered are automatically correctly placed in the topology tree.




The example shows 8 meters discovered by scan function.




8.3 Offline devices

To configure devices that is not online, do “Add Mbus Node (General)”.




You need either the primary or the secondary address of the Mbus-meter to be able to add it manually to the topology. It is also necessary to select address mode to primary/secondary depending on the address you enter.



9 Copy, backup and restore

You can copy all or part of the tree in the topology and then copy it to another part of the tree or to another project. Right click and select copy (CTRL + C) then paste(CTRL + V).

You can also do a full backup of your IMC project. This is done by first selecting "Backup" tab at the top.



Create

Create a new server backup
(With option to copy or move the backup to a client when finished)

Delete Backup

Delete a server backup

Upload

Upload a locally saved backup to the server

Copy to Client

Copy a locally saved backup to the client

Move to Client

Copy a backup file from the server and save on the client and then delete the backup file on the server

Restore

Restore a server backup




10 Creating integrated functionality

IMC places all of your building’s systems on a common platform. This enables you to converge the functionality from several different systems to vastly increase their scope and utility.

10.1 Generic info on creating calculation objects.


Much of the integration logic is created in the “Objects” part of topology tree. The different objects that can be added (version 1.0) are:



10.2 Generic info on object references.

The different object types can have references to other nodes as input or output.

For the input reference an Update interval for the node can be set. There is also a setting Readout Timeout (default is set to 0) an asynchronous call will be made, and the node will have a new value next time it is read. It can also be set with a timeout 1-5 seconds, which will make it possible to wait for a “fresh” value on the reference node, which can be useful when running jobs.




10.3 AQ – Analog Calculation Object

The analog calculation object is used to perform a calculation between a number of analog inparameters

It is possible to perform more advanced calculations using a script language.

For more “ease of use” there is also a number of standard calculations included, similar to those in KTC PLC: s. (Min,Max,Average) etc.

In this example, we first create a “object directory node” by right-clicking in topology tree. The node is called “_Examples”. The result should similar to below, although only with “Examples” and not all the AQ in the picture.



Next step is to right-click _Examples, select add, select “AQ – Analog Calculation Object”.

You will get a dialog box locking like the one below.



New Node Type:
AQ - Analog Calculation

Parameter Templates

ID Evaluate Function Variables Geography Colors Help Expression Help

ID:
[text input]

Required User Privilege:
[dropdown]

Name:
[text input]

Class:
Other [dropdown]

Lifecycle Phase:
Installation [dropdown]

Enabled

Meter Location ID:
[text input]

Meter Number:
[text input]

The below table describes the fields involved. Suitable name standard might be to number the objects and a description of the purpose. Example AQ01 – Lowest Room Temp.



Properties

Node Type:
AQ - Analog Calculation

Parameter Templates

ID Evaluate **Function** Variables Geography Colors Help Expression Help

Function:
Min

Expression:

Unit:
°C

Nodes in Topology:

Ref01: AV01 - VS21-GT11 Tillopp (DUC-TEST.DUC001.AV01)

Ref02: AV04 - TA7-GT41 FV (DUC-TEST.DUC001.AV04)

Ref03: test2 (test2) (Netbiter Modbus Gateway.Modbus module.test2)

Nodes selected for this function:

- DUC-TEST.DUC001.AV01
- DUC-TEST.DUC001.AV04
- Netbiter Modbus Gateway.Modbus module.test2

Add new items


Revert OK Cancel Apply




10.4 AT - Average Temperature Object

There is a special object in IMC to calculate average temperature. You can use script functions to perform the same functionality, but the AT Object simplifies this calculation. It is typically used to control heating for a building by using average room temperature instead of heating flow.

Create an AT Object by adding this to objects in topology.



Next step is to select the room sensors and set the parameters on the Function Tab





Minimum Number of Values OK

To avoid controlling when many sensors are lost, it is possible to set minimum number of sensors. If less sensors than minimum, the average will be “sensor error”

Remove Highest Count

If a number > 0 is entered, the algorithm will exclude the x highest temperatures from average calculation, where x is the number entered,

Remove Lowest Count

If a number > 0 is entered, the algorithm will exclude the x lowest temperatures from average calculation, where x is the number entered,

Unit:

Normally select °C here.

Nodes in Topology

Select the temperature sensors to include in calculation here,

10.5 AV - Analog Value Object

Used to create analog alarm from third party devices (eg Modbus).
See Section 8.1 for more information.

10.6 DQ – Digital Expression Object

Similar to the AQ object but used for digital signals.
Expressions are made using AND/OR commands.

Expression Help

The following examples has three named boolean values, v1, v2 and v3.

Logical Or writes as OR, ELLER or ||

v1 || v2

v1 ELLER v3

Logical And writes as AND, OCH or &&

v1 && v2

v1 AND v3

Logical Exclusive Or writes as XOR

v1 XOR v2

Negation writes as NOT or !

!(v1 || v3)



10.7 DV - Digital Value Object

Used to create digital alarm from third party devices (eg Modbus). See Section 8.1 for more information.

10.8 HO - Holidays Object

This node tells if the current day is a holiday or not. Select which nations holidays you want. The readout result will be:

Status

True if the current day is a holiday.

Holiday name

If it's a holiday, the name of the holiday will be presented here.

10.9 LR - Linear Regulator Object

Used to do a linear curve with two breakpoints.

10.10 RW - ReadWrite Object


This node reads value from a node and writes that value to another node. It continuous checks that the values is the same on both sides. The input and output of this node is configured by its child nodes. No parameters to be set on this node.

10.10.1 Node Reference Input

The value of this node represents the input value. If more than one node is added, the sum of all nodes will be the input

10.10.2 Node Reference Output

The output node is the node which this node writes to. The value of this node will always be the same as the input to this node. On the reference properties fields can be selected which shall be written.





10.11 ST State Object

10.12 ST State Sequence Object

10.13 SU - SunTimes Object

This node calculates the sunrise and sunset for a specific position. Enter the longitude and latitude for the position. The readout result will be:

Status

True if the sun is up.

Sunrise

Timepoint for the sunrise the current day.

Sunset

Timepoint for the sunset the current day.

10.14 TM - Thermostat Object

Used to do thermostats function with on and off- time delay.

10.15 TU - Timeschedule Object

Time schedule with a free number of periods. Add a TimeSchedulePeriod Node for each period. The result is the combined result of all periods. If one or more period is evaluated to true, the readout result of this node will be true.

Auto

All periods are evaluated, and the readout result will be the evaluated result.

True

Readout result is always true.

False

The readout result is always false.

11 Reading data from IMC

There are different ways for IMC to expose data to other computer systems, like Scada, information panels, mobile apps, etc.

11.1 OPC-UA


Described under Connecting to KTC Scada.

11.2 Fast API

Fast API (Fast is a short Swedish for estate) is a standardized web API (rest) developed by Swedish estate owners to facilitate handling of building data. KTC has implemented a subset related to meter readings and consumption data.

Nodes are defined by the setting Meter Location ID.

Operator must define where to find meter and consumption data. This is done in settings, in the tab for Fast API:



The screenshot shows a 'Properties' dialog box with the 'Fast API' tab selected. The 'Node Type' is set to 'Settings'. The 'Parameter Templates' section includes tabs for 'Ports', 'SMTP', 'Settings', 'Network', 'Opc UA Server', 'Alarm', 'SrdLink', 'Quality control', and 'Fast API'. The 'Fast API' tab contains the following configuration fields:

- Fieldsink to read consumption data:** HourValues
- Consumption field names:** Consumption*
- Consumption period:** Hour
- Fieldsink to read meter data:** Localhost
- Reading field names:** Energy Value


At the bottom of the dialog, there are buttons for 'Revert', 'OK', 'Cancel', and 'Apply'.



12 Creating IMC Alarms and Trend Data

12.1 How to set up polled Alarm using AV/DV Objects

To create polled alarms, we use the AV / DV objects (for SRDLink alarm see further down in this manual). First a physical Object (eg Modbus objects) needs to be linked to an AD / DV Object. After this you have to set the alarm options via the "Alarm" tab described below. Via the "Evaluate" tab it's possible to set the time for the polling interval (default is 60sec).



Priority *required*
Off, A,B or C

Delay *required*
Time delay for the alarm.

AlarmInterlock *optional*
Ability to connect an object to use for interlock of the alarm.

Self acknowledge alarm *optional*
(AutoAcknowledge) If the alarm should be autoacknowledged or not.


Low limit *required*
Low alarm limit setpoint.

High limit *required*
High alarm limit setpoint.



12.2 How to set up polled Trend Data



IMC is able to poll trend data. This is done using a predefined job named "ReadoutMomentary_10min". By connecting objects to this job, you will enable trend on these signals. Objects are added via the "nodes" tab in the "ReadoutMomentary_10min" job. Alternatively, you can drag objects from the "Topology" to the job.







12.3 How to set up Alarms for SRDLink devices

Alarms from SRDLink devices are activated in the "SRDLink Gateway" and the "DUC (SRD Link)" by checking the "Scan alarms" box. The IMC will then poll the activated alarms in KTC SRD Link devices.





Note: You can also configure the SRDLink devices to send alarms to the IMC. This requires that a receiver is set up in **SRDLinkServer**. Typically, this receiver address will be set to "0". This is not necessary but will speed up the alarm handling as it will be handled as an event.



12.4 How to set up Trend Data for SRDLink devices


SRD devices have built-in-trend buffer. At IMC, we can determine which object we want to retrieve history from and save in the IMC database.

There are several ways to activate history on the objects.

1. Using **SRDLink View**
2. On each object
3. Several at once using the details Topology


12.4.1 Activate Trend Data collection via SRDLink View

Mark the **Topology** tab and select **View / SRDLink View**.






Select the SRD device you want to activate Trend Collection on. In SRDLink View window, you will now get the option to enable collection of history on each individual object. This is done by expanding the object and then tick the Value box.



12.4.2 Activate Trend Data collection manually on every object


Select the object you want to activate Trend Collection on through the Topology tree and select Edit (F4). Select the tab "History signals" and the Add New Items "Value".





12.4.3 Activate Trend Data collection on several objects at the same time


Select the object you want to activate Trend Collection on in the Details Topology. Select Edit (F4). Select the tab "History signals" and the Add New Items "Value". All selected object will now be activated.






12.4.4 General settings for the retrieval of historical values.

Start by opening **Data Source/Metering/Jobs**.




Mark **ReadHistory** and select Edit.





Choose Execution to change the setup for scheduling of the job.



This job is active for scheduling *required*

If not selected the scheduler will never schedule this job for execution.

Scheduling interval type *required*

Specify interval type used by the scheduler to determine next execution time.

Scheduling interval *required*

Specify the interval used by the scheduler to determine next execution time. For instance '2' results in scheduling every other of the type specified(hour, day, etc)

Start scheduling *required*

Enter the day for when the scheduler starts scheduling the job. If empty, today is used as starting point for scheduling.

Stop scheduling *required*

Enter the day for when the scheduler ends scheduling the job. If empty, the scheduler keeps schedule new execution times forever.

Start time *optional*

Enter the time of day for the execution to begin(scheduling is performed during the start-end time interval, using execution to decide how often). If not specified the start of the day is used.

Retry times *optional*

Specify the number of retries the job does for erroneous results. Only erroneous results are retried. If specified to 0 no retries will be performed by the job.

Retry type *optional*

Specify interval type used by the job to determine next retry time.

Retry interval *optional*

Specify the interval used by the job to determine next retry time. For instance '2' results in retries every other of the type specified(hour, day, etc)




13 Creating IMC Web GUI

13.1 Creating a slide Show

The building manager accesses the system via a web interface. This interface can be customized to present a view of the functions the manager finds most pertinent to his/her specific application. Included in customization is an opening Slide that presents the functions, readouts, menus etc. that a building manager wants to see immediately upon opening the page.

The following is an example of the web interface that is used by a building manager to monitor the system.


In this view, you can see an example of the opening page with a customized slide show that presents the selectable items specific to the managers primary daily concerns for that building. Note that you can create any number of pages and browse through them upon opening the interface:







A slideshow is composed as follows:

Open the **IMC/Slide** datasource:



Right-click the root node selecting the **Add /Slide Directory Node** option:






- Header** *required*
Header of the slide.
- Number of columns** *required*
Number of columns, one or two. Two columns only available when image position is center.
- Sort order** *required*
Which order the header will be displayed.
- Image position** *required*
Left, right or center
- Scale to fit** *Optional*
Scale image to fit on slide.
- Upload image** *Optional*
Upload an image to show as background in the slide

After this you have to add **SlideHeaderNode** and **SlideNodeReference**.

SlideHeaderNode is a superscription and **SlideNodeReference** is a link to your dynamic object in the topology.



- Text** *required*
Text to display.
- Sort order** *required*
Which order the text will be displayed.



Properties

Node Type:
SlideNodeReference

Parameter Templates

Content

Reference:
DUC-TEST.DUC001.AV01
Select reference

MenuName:
VS21-GT11 Tillopp
 Read menuname from reference

Sort order:
2

Show this fields:
Add new items

Update interval:
5

Userlevel write:
DRIFT

Revert OK Cancel Apply


- Reference** *required*
Enter a node ID specifying the reference to a node
- Menu Name** *Optional*
This name will be shown in the menu.
- Read menu name from reference** *Optional*
Read the menu name from the node reference.
- Sort order** *required*
Which order the values will be shown.
- Show this fields** *Optional*
Default field is Value. Here you can change it to another.
- Update interval** *required*
Update interval in seconds for this node.
- Userlevel write** *required*
Minimum userlevel for configure node.

A typical slideshow image may look as below.

Home Back Help KTC Tech Test2 Admin 2014-03-12 16:08 Wed

Building A

| | |
|-------------------------|----------|
| Temperatur Framledning: | |
| VS21-GT11 Tillopp: | 19.41 °C |
| Temperatur Retur: | |
| TA7-GT41 FV: | 56.51 °C |






13.2 Creating a menu


In addition to slideshows, you can create system-specific menus tailored to the end user needs. In the user menu, you can change setpoints, alarm priority, etc.


A menu is composed as follows:

Open **DataSource/IMC/Menu**:



Start by adding a **Menu Directory Node**:






Name *required*
Name of the node. It appears in the tree.


Sort order *optional*
Used to sort the nodes in the tree.

Icon *optional*
Ability to connect a picture/icon to the **Name**.





Icon *optional*
Select picture/icon to upload.

Note: to activate the icons. Choose **MenuRootNode /Content** and select Show mode: Icon





When you are satisfied with the structure (**Menu Directory Node**) it's time to continue with **Menu Node Reference**. Use the **Menu Node Reference** to link the objects that you have in the Topology tree together with your user menu.



Reference *required*
Select the reference to the object you want to show in the menu.

MenuName *required*
The name shown in the menu.

Read menu name from reference *optional*
Read the menu name from the node reference.

Sort order *optional*
Used to sort the nodes in the tree.

Show this fields *optional*
Ability to customize which fields to display. Default is Value.



Update interval *required*
Update interval in seconds.

Userlevel write: *required*
Minimum userlevel for configure node.

Enable configuration *optional*
Enable configure node or not.



Example: Configuration as below provides the following web interface.





The screenshot displays the KTC-IMC configuration interface. On the left, a 'Menu' tree shows a hierarchy: Mainbuilding > 003-HVAC > 000-VS21 > 001: AV01 - VS21-GT11 Tillopp > 001: AV01 - VS21-GT11 Tillopp. The selected item is highlighted. On the right, the 'Properties' dialog for this menu item is open. The 'Node Type' is 'SubMenu NodeReference'. The 'Parameter Templates' dropdown is set to 'Content'. The 'Content' section includes: 'Reference' (DUC-TEST.DUC001.AV01), 'MenuName' (VS21-GT11 Tillopp), a checked 'Read menuname from reference' checkbox, 'Sort order' (1), and a list of fields to show: AlarmHighLimit, AlarmLowLimit, and AlarmStatus, each with a red 'X' icon. Below this is an 'Add new items' button. The 'Update interval' is 5 and 'Userlevel write' is DRIFT. At the bottom are 'Revert', 'OK', 'Cancel', and 'Apply' buttons.



Web Interface:

Home Back Help HVAC



003-HVAC

Home Back Help HVAC

...

VS21

VS22

VS23

VS24

HVAC

Home Back Help HVAC\VS21 Admin 2014-03-05 08:48 Wed

...

VS21

VS21-GT11 Tillopp: 19.42 °C

Home Back Help HVAC\VS21 Admin 2014-03-05 08:49 Wed

...

VS21-GT11 Tillopp : 19.42 °C


| | |
|-----------------|-------------|
| AlarmHighLimit: | 17.00 |
| AlarmLowLimit: | 5.00 |
| AlarmStatus: | B Hi Active |




13.3 Creating a TrendView


A TrendView is composed as follows:

Open the **IMC/Trendview** datasource.



Right-click the root node selecting the **TrendView Serie Node**.







| | |
|---|-----------------|
| Name | <i>required</i> |
| Name on the TrendView | |
| GraphType | <i>required</i> |
| Line/Curve | |
| ReadoutType Day | <i>required</i> |
| Select type of values to read from fieldsink in day mode. | |
| Raw/Hour/Day/Month | |
| ReadoutType Week | <i>required</i> |
| Select type of values to read from fieldsink in week mode. | |
| Raw/Hour/Day/Month | |
| ReadoutType Month | <i>required</i> |
| Select type of values to read from fieldsink in month mode. | |
| Raw/Hour/Day/Month | |
| Use Min/Max | <i>optional</i> |
| If checked, the Min/Max settings will be used. | |
| Min | <i>optional</i> |
| Min value in graph. | |
| Max | <i>optional</i> |
| Max value in graph. | |
| Fieldsink | <i>required</i> |
| Select fieldsink to read data from. | |
| Minutes Shown in logview | <i>required</i> |
| Minutes shown in logview. | |



After this you have to connect your node reference (max 4 per TrendView).

Right-click on the **TrendView Serie Node** and select **Node Reference Trend**.



- Reference** *required*
Enter a node ID specifying the reference to a node.
- Name** *required*
Name shown in graph
- Read menuname from reference** *optional*
Read the menuname from the node reference.
- Read this field** *optional*
Select the field you want to read. Default is Value.
- Color** *required*
Select color.

14 Connecting to KTC Scada

The IMC has built-in support for OPC UA, which we use when we want to communicate with KTC-SCADA. We use the tool KTC Manager to add a new data source to establish communication with IMC OPC UA. Things to consider is that the OPC UA communicates on port 7000 and that in this case we are using OPC UA Alarms and Trend.

| | |
|---|--|
| Datakälla | |
| Namn | IMC |
| Tagseparator | . |
| Taggprefix | i |
| OPC-UA | |
| Sökväg OPC-UA-server | opc.tcp://xxx.xxx.xxx.xxx:7000 |
| Namn på server i OPC-UA-konfiguration | |
| Topology | |
| <input checked="" type="checkbox"/> OPC UA Alarm | <input checked="" type="checkbox"/> OPC UA Trend |
| OPC UA Användarnamn | |
| OPC UA Lösenord | |
| ManodoTrendAlarmService | |
| Serveradress | - |
| DCOM-namn (Samma som i Matrikon) | - |
| Trend & Alarm Insamlingsjobb (från KTC AdeptoOPC till Scada-databasen) | |
| Scada-databas (linked server, dest.) | |
| (Obligatorisk, tomt fält medför att befintliga jobbparametrar tas bort) | |
| OPC Databas | |
| OPC Job Databas | |
| (Valfritt, tomt fält medför att resp. jobbparametrar ej skapas) | |



15 Creating IMC dynamic flowchart/diagram

Starting with version 1.2 the IMC has support for creating dynamic diagrams. Construction of the diagrams is done using an additional module to the CMT tool called Diagram Designer.

In short, construction of diagrams is done by adding dynamic symbols and value boxes onto an imported background. The background image may be in the format BMP, JPEG, PNG, or TIFF.

More simple drawing functions such as Ellipse, Line, Polygon, Polyline, and Rectangle are available in version 1.2

Dynamic color changes, for example on sensors and fan symbols are made in version 1.2 by using conditions to switch between different static images.

It is also possible to save dynamic object to the Designer library. Some standard symbols are supplied at installation, but the idea is that the user expands this library for their own specific needs.


15.1 How to create a new diagram

15.1.1 The Diagrams tab


Diagrams are used to add new or edit existing diagrams. There is also an opportunity to preview the results of the work done in the "Diagram Designer".

Diagrams tab is opened via the "Data Source / Diagrams / Diagrams".

New diagrams and folders are added as follows:



How to preview or view a previously produced diagram via Diagrams View is shown below:





15.1.2 Start Diagram Designer

Open Diagram Designer by right-clicking on the "Custom Diagram" you want to edit and select Diagram Designer.



15.1.3 Adding a background image

In Diagram Designer, right-click on the diagram and choose from the selections below:



Width Width of the imported image in pixels.

Height Height of the imported image in pixels.

File Name File name of the image.

Upload new image file If checked, you can upload a new image file to the location specified above.


File to upload File to upload and save to the location specified above.

15.1.4 Create a diagram link


Start by dragging a link symbol from "Library" or create a new symbol that you want to use as a link.
Alt.1



Right click on your symbol and select Add / Diagram Link.




Select the diagram you want to create a link to.




Alt.2

Make sure the drag / drop behavior is set to "Create Diagram Link".




Hold down the "Alt" key and drag the diagram to the symbol you want to create a link to.




15.1.5 Creating a value box




Start by adding a new Label.




Fill in an ID name under the "ID" and a text string under "text."



To attach a Node to the Label can then be done in two ways.
Alt.1 Right-click on your new "Label" and select "Node Field Connection."



Symbol Property will in this case be Text. Select the node you want to be displayed, and finally which field on the selected node to be displayed.




Alt.2

Make sure the drag / drop behavior is set to “Create Node Field Connection”.




Select the node that you want to connect with the "Label" by dragging the Node from the Topology tree. Symbol Property will in this case be Text and finally select the field to be displayed.



15.1.6 Creating a new dynamic symbol


Dynamic color changes, for example on sensors and fan symbols are made in version 1.2 by using conditions to switch between different static images.

Add a "Script symbol"







Enter an ID that will harmonize with the symbol to be created.




Also enter the width and height of your symbol in the General tab.



Add the static images to be used in the symbol. Mark your new Script Symbol and select/add State images.




State image 1




State image 2

After this, we want to determine the condition that is the basis for the shifting of the static images. The first thing we must do is to add the Script parameters / input parameters. In this example, we want a sensor symbol to change from "white" to "red" when the alarm is active. In this case we need to create a "Double Parameter".






Fill in an appropriate name of "Parameter Name" and "Header".




Go back to the "Input Parameters" and create your script:






What now remains is the "physical" connection to the node. This connection is created by adding a "node field connection". Symbol Property is chosen to the one we created in the "Input Parameters", in this case "Alarm Status Sensor".






15.1.7 Creating an editable value box


Add a "Text Edit Control"



Enter an ID that will harmonize with the object to be created.




Enter the width and height of the text box under the General tab.






Add a "Node Field Connection"

Select "Value" in Symbol Property and edit the Node ID and Field.



In order to write down to the node, we also need a "Node Control Parameter Connection" as shown below.





15.1.8 Create a description that is linked to the Diagram

When the users open a diagram via the web interface (or via the app.) he will have a description




symbol up in the left corner by default .

When the user clicks on this icon he will get up a customized text that usually describes the function of the specific diagram.


How to create or edit this text is shown below.

1. In CMT/ Diagrams, mark the current diagram and select edit.
2. Select the General tab and then type or paste your text in the description.




15.2 How to save Objects to library

1. Select the object in the diagram canvas that you want to save as a symbol.
2. Open the Library tab and select the folder where you want the symbol to be saved.
3. Click "Add Diagram" and select "Add Diagram Containing Selected Objects in Diagram Canvas".






4. Choose an appropriate name for the symbol and click OK to save.




5. Open the newly created symbol/diagram in Diagram Designer and adjust the width and height so it harmonizes with the symbol.
(This is to more easily place the symbol in the right place when you create diagrams with symbols.)



15.3 How to Copy/Paste and XML Export/Import of Custom Diagrams and Folders in the Diagrams/Library data sources

15.3.1 Copy/Paste objects in the Diagrams/Library data source from Server 1 to Server 2


1. Start a CMT and login to Server 1
 - a. Open the Diagrams/Library data source
 - b. Select the objects that you want to copy, such as some Custom Diagrams or Diagram Folders. In the example below, a number of child objects under the root object are selected.
 - c. Right click and select **Copy** with the option **Copy Objects and Export XML to Clipboard – Include Detached Data Content**



2. Start a second CMT connected to Server 2
 - a. Open the Diagrams/Library data source
 - b. In the data source, select the **Parent** object to which the objects will be pasted. In the example here, the root object is selected as the parent.
 - c. Right click and select **Paste**.
 - a. **Note: Paste** corresponds to an **Import XML** scenario with the import option **Create New Objects**.
 - d. The new objects and all the file content are pasted at Server 2.

15.3.2 Export/Import objects in the Diagrams/Library data source from Server 1 to Server 2

1. Start a CMT and login to Server 1,
 - a. Open the Diagrams/Library data source
 - b. Select the objects that you want to copy, such as some Custom Diagrams or Diagram Folders
 - c. Right click and select **Export XML To File** with the option **Export XML of Objects – Include Detached Data Content**.
 - a. **Note: When Detached Data Content is included** in the export, it is **recommended to use Export XML To File (NOT Export XML To Editor)**, as the detached data can be very large. This will export the content directly to a file instead of open the XML for the exported data and the file content in the editor.
 - d. Save the exported data to a XML file.




2. Start a second CMT connected to Server 2
 - a. Open the Diagrams/Library data source
 - b. In the data source, select the Parent object to which the objects should be imported, e.g. the root object.
 - c. Right click and select **Import XML From File** with the import option **Create New Objects**.
 - d. Select the file exported from Server 1, and click Open.
 - e. The new objects and all file content are imported to Server 2.

16 Using new Web Interface


The new web interface is located on port 8080 under the address: “<IP address-IMC>:8080/KTCImc/”

The username and password are the same as already used for logging in to other Clayster features in the IMC, such as CMT and the older web interface.



16.1 Information Page

The first page on which you end up after a successful login is the information page. Here you will find information about the current version, licenses used to include max limit, MAC address and IP information. The information page is also available from the menu selection at the top of the Information button.



16.2 Navigation Menu

Under the navigation menu you can log out, access the information page and a menu with settings.



16.3 IP settings

Under this page, the IP settings can be changed for the network adapter. It is possible to change IP address, subnet mask, default gateway and DNS-servers.

After saving new IP settings, there will be a delay of 25 seconds before the new settings are implemented. If the settings have been saved by mistake or if incorrect data has been saved, it is possible to undo this within the time interval, by clicking Undo Settings.



Inställningar

DHCP - Server

IPAdress
192.168.102.132

Netmask
255.255.255.0

Default Gateway
192.168.102.1

DNS Server 1
192.168.102.1

DNS Server 2
0.0.0.0

SPARA INSTÄLLNINGAR

16.4 License

Under license, existing license can be replaced. Click Select File, locate your new license file on your computer and select Load. After the new license file has been loaded, the IMC will restart.



För att ersätta licensen som körs i IMC:n, välj en ny licens och klicka på "Ladda".

Obs: Installation av ny licens kommer innebära att IMC-programvaran startas om.

Välj fil Ingen fil har valts

LADDA

16.5 Time Settings

During time settings, time and date can be changed. It is also possible to see the current ntp server against which the IMC is synchronized, as well as the current time and the current server's time.

IMC tidsinställning

Aktuellt datum och tid i IMC 2019-09-20 08:43:29

Tidsserver (NTP-Server)

Aktuell tidsserver(ntp-server) på IMC time.windows.com

Tidsservers(ntp-server) aktuella tid 2019-09-20 08:43:30

Ändra datum och tid

Välj datum

9/20/2019



Ställ in ny tid


08:43

SPARA INSTÄLLNINGAR

16.6 Backup functions

During the menu selection backup functions, it is possible to create new backups, download backups, restore from a backup and delete existing backups. Select the backup to be downloaded, restored or deleted and click on the button for the desired function

There is also an option to upload your own backups to the IMC. Click Select File and select a file backup file from your computer that you want to upload, then click Upload Backup.



Backuper på enheten


| | |
|-------------------------------|--------------------------|
| 2018-03-28 14-20.cbk | <input type="checkbox"/> |
| 2018-06-29 15-17 imc.test.cbk | <input type="checkbox"/> |
| 2019-03-12 11-11.cbk | <input type="checkbox"/> |
| 2019-09-09 13-02.cbk | <input type="checkbox"/> |
| 2019-09-09 13-24.cbk | <input type="checkbox"/> |
| 2019-09-12 10-12.cbk | <input type="checkbox"/> |
| 2019-09-12 14-09.cbk | <input type="checkbox"/> |
| 2019-09-17 11-04.cbk | <input type="checkbox"/> |
| Backup_20190705_0855.cbk | <input type="checkbox"/> |
| Backup_20190816_0943.cbk | <input type="checkbox"/> |
| Backup_20190816_1010.cbk | <input type="checkbox"/> |

Ladda upp egen backup till IMC

Välj fil

16.7 Factory Reset

This feature is used to perform a complete factory reset of the entire system. Database, all configurations, charts, etc. will be deleted and all settings will be restored to the original. The only thing that will be saved is the license file, so make sure all settings, charts, etc. have been backed up before a factory reset is done.




Fabriksåterställning av IMC

Denna funktion används för att fabriksåterställa IMC:n. Enheten kommer efter återställningen att startas upp igen automatiskt med fabriksinställning. Åtgärden kräver administratörsrättigheter.

Observera att samtlig data, alla inställningar, konfigurationer och alla databaser kommer att raderas från enheten. Det enda som sparas är enhetens licensfil.


16.8 Restart IMC

This function is used to restart the system. The options that can be selected are, Restart IMC service, which restarts the IMC software itself. The other option is Full System Restart, which restarts the entire system, including the hardware.



16.9 Create Exports for Skanska Energy Box and Energy Portal

To create exports, navigate to Konfiguration -> Skapa exporter



This will show a page where you can choose if you want to create and export for Skanska Energy Box (SEB) or Energi Portalen.

Before you create export, a sender mail should have been configured in the IMC, using CMT -> Settings -> SMTP -> From. This address will be used in the template created.

16.9.1 Erase Exports


The IMC can hold two exports, one of type SEB and one for Energi Portalen.

If there is any previous configuration, they will be shown under "Befintliga export-konfigurationer på IMC:n". They can be marked as deleted by clicking "Radera Export".



16.9.2 Create new exports

To create a new export, choose the type you want and fill in export information such as project name etc. No white spaces, trailing spaces or special character (except dash and underscore) allowed in project name and number.



Skapa ny export

Skapa export för Skanska Energy Box (SEB)
 Skapa export för Energiportal

Projektnamn:


Projektnummer:

E-postmottagare för export:

SKAPA EXPORT

Lyckades! Exporten har sparats på IMC:n.


Then to create the export, click on “Skapa Export” If success, the green bar will be lit. If it already exists an export of chosen type, following message will appear.



SKAPA EXPORT

Export already exists

If the export can't be created due to communication error or similar, this field will show.



SKAPA EXPORT

Kommunikationsfel! Unknown Error